

LD-7 WATER LEAK DETECTOR



KEY FEATURES

- 1 Amplifier w/volume & mute switch
- 2 Sensor w/3 point ground plate
- 3 Magnet base
- 4 Stereo headphones
- 5 3 section contact rod

FEATURES

- ▷ Compact amplifier (with mute switch) fits inside the palm of the user's hand. Press the mute switch (on/off) to activate the leak sounds in the headphones, and then release the mute switch when moving the sensor (protects your hearing!).
- ▷ Designed for all of the water leak detection applications, including leak surveys and leak pinpointing. Use the 3-point ground plate for pinpointing on streets and concrete slabs. Use the magnet base or the contact rod for leak surveys at hydrants, valves, or meters.
- ▷ Extremely compact and lightweight. The entire LD-7 inside its heavy duty carrying case measures only 14 inches x 10 inches x 6 inches, small enough to be stored behind the seat inside the cab of the truck.
- ▷ 5 High Frequency filters, 3 Low Frequency filters (plus Low filter OFF), and 2 Notch filters (plus Notch filter OFF) to remove continuous interfering noises from A/C hum, motors, wind, etc.
- ▷ Hard ABS plastic custom carrying case included.

SPECIFICATIONS

AMPLIFIERS

- ▷ Input Impedance: 430k ohm +/- 1%
- ▷ Output Impedance: 4-10 ohm
- ▷ Amplification: 56 dB +/- 3%
- ▷ Frequency Range: 100Hz to 1500Hz
- ▷ Power: 2 AA dry cell batteries (1.5 V x 2)
- ▷ Power Consumption: 20 mA Nominal (30-hour life)
- ▷ Weight: 0.507 lb. (230 gm)
- ▷ Size: 5.7" x 3" x 1.25"
(145mm x 30mm x 68mm)

HEADPHONES

- ▷ Impedance: 20 ohms

ABS CARRYING CASE

- ▷ Weight (full): 5.84 lbs (2.65 Kg)
- ▷ Size: 14" x 10.5" x 6"
(356mm x 267mm x 152mm)



По вопросам продаж и поддержки обращайтесь:

Архангельск (8182)63-90-72
Астана +7(7172)727-132
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Казань (843)206-01-48

Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81
Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41

Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78

Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

Единый адрес: sca@nt-rt.ru | <http://subsurface.nt-rt.ru>